Standex Electronics

PARTNER | SOLVE | DELIVER®

# Power Magnetics for Medical Applications

## How custom magnetics play a pivotal role in ensuring efficient power delivery, reliable isolation, and patient safety within medical devices.

*High-frequency magnetics—chiefly transformers and inductors used in switching power supplies—play a critical role in providing patient isolation in medical devices. These magnetics enable power conversion and signal coupling while meeting the strict IEC 60601-1 isolation and safety standard. Below is an overview of how high-frequency magnetics are applied and what design considerations must be addressed in medical applications:*

## Why High-Frequency Magnetics Are Used

1. **Efficient Power Conversion**
    - High-frequency operation (tens of kHz to several MHz) allows smaller and lighter transformer/inductor cores, reducing size and weight—important in compact or portable medical equipment.
    - Higher frequency also improves regulation and transient response in switch-mode power supplies (SMPS).
2. **Isolation Requirements**
    - In medical devices, galvanic isolation is required to protect both patients and operators from potential electrical shock.
    - High-frequency transformers provide the means to pass power across an isolation barrier while respecting creepage and clearance distances.

## Key Safety Standard (IEC 60601-1)

When designing magnetic components for medical power applications, engineers must comply with IEC 60601-1, which addresses:

- **Creepage and Clearance Distances:** Minimum distances are set between conductive parts across an insulation barrier (creepage) and through air (clearance).
- **Reinforced or Double Insulation:** Higher-level isolation can be required depending on the device's patient-contact classification (e.g., Type BF, CF).
- **Dielectric Strength:** Transformers need to withstand high-voltage (HV) dielectric test levels (often in the range of 10 kVAC or more) to ensure no breakdown under normal or single-fault conditions.
- **Leakage Current Limits:** Leakage current from the device to the patient must remain under strict limits.

## Design Considerations for Magnetics in Medical Devices

1. **Core Material Selection**
    - Ferrite materials are commonly used for high-frequency operation due to low core losses at tens of kHz to MHz range. Polymer and powder cores can also be used.
    - Core shape (E, EE, ETD, PQ, planar cores, etc.) impacts thermal performance, winding layout, and overall size.
2. **Thermal Management**
    - Transformers can generate heat from core and copper losses.
    - Medical devices must operate within strict temperature limits — both for safety and to avoid failure.


3. **EMI and Noise**
    - High-frequency switching can introduce electromagnetic interference.
    - Common-mode chokes or integrated EMI filters are typically used to meet medical EMC standards (e.g., IEC 60601-1-2).
    - Winding strategies (e.g., interleaving) help reduce leakage inductance and improve efficiency but can increase parasitic capacitances, so trade-offs are needed.
4. **Partial Discharge (PD) and Dielectric Integrity**
    - At high voltages and frequencies, partial discharge can degrade insulation over time.
    - Careful material choices (e.g., high-grade insulating films, epoxy) and design practices (adequate spacing, proper potting) help minimize PD risk.
5. **Leakage Current**
    - Meeting leakage current limits is critical, especially in contact or invasive medical devices (CF devices).
    - Minimizing stray capacitance between primary and secondary helps keep common-mode leakage current within standards.

## Conclusion

High-frequency magnetics are essential in modern medical devices due to their efficiency, reduced size, and ability to meet strict isolation requirements. By following IEC 60601-1 guidelines and implementing robust design and manufacturing practices—especially around insulation, creepage and clearance, leakage currents, and partial discharge prevention—engineers can ensure patient safety and regulatory compliance. The result is a compact, reliable, and efficient power or signal isolation component that supports the lifesaving functionalities of medical equipment.

PARTNER | SOLVE | DELIVER®

**Standex Electronics**

**Standex Electronics**
**Worldwide Headquarters**
4150 Thunderbird Lane
Fairfield, OH 45014 USA
+1.866.STANDEX (782.6339)
info@standexelectronics.com

Agile Americas (NH)
+1.800.805.8991
info@agilemagco.com

Minntronix Americas (SD)
+1.605.884.0195
productsales@minntronix.com

Renco Americas (FL)
+1.800.645.5828
sales@rencousa.com

StandexMeder Europe (Germany)
+49.7733.9253.200
salesemea@standexelectronics.com

StandexMeder Asia (Shanghai)
+86.21.37606000
salesasia@standexelectronics.com

Standex Electronics India (Chennai)
+91.98867.57533
salesindia@standexelectronics.com

Standex Electronics Japan (Kofu)
+81.42.698.0026
sej-sales@standex.co.jp

IATF 16949 CERTIFIED | ISO 9001 CERTIFIED | ITAR | NIST | AS9100 CERTIFIED

**standexelectronics.com**

MAG-COM-WP250201